MODE COM

User Manual

ENERGY OPTICAL MOUSE

MC-602

MODE COM

ENERGY OPTICAL MOUSE

MC-602

Introduction

Thank you for choosing a high quality computer mouse MC-602.

The computer mouse MC-602 has been created with a view to the customers who work with notebooks.

Owing to the compact size, the mouse is not only an ideal match for a portable computer but is also very functional. A wireless technology ensures the comfort of use in a distance of 2 meters from the computer. Additionally, MC-602 is an energy saving device. Its characteristic features are: the resolution of (800 DPI) and high quality. The USB receiver incorporates unique and extremely comfortable solutions of storing the receiver at the bottom of the mouse.

Mode Com places a high value on the quality of its products to not only fulfil but also surpass customers requirements. Products are created with the modern view and the latest technology in mind.

Choose better future
– choose Mode Com!

Package Contents

Wireless Mini Optical Mouse

Mini USB Receiver

2 × AAA Batteries

English Manual

The Description for Each Part



Hardware Installation

• Installing Batteries

The Steps of installation:

Step 1: Press Switch.

Step 2: Pull out the battery cover from the cover of your mouse.

Step 3: Insert two AAA Alkaline Batteries into the battery compartment, replace the cover carefully.

Step 4: Once the battery is placed correctly in the mouse, the optical LED located at the mouse bottom will light up.



Establishing a Communication Link

The Wireless mouse is „Plug & Play". It's not necessary to set the channel for the products. lf you find the mouse can not work smoothly or the mouse has been interfered by the neighboring wireless product or you change the new battery, you can take the following steps:

Step 1: Reconnect the receiver of the mouse and find the new ID.

Step 2: Press the reset button on the bottom of mouse.

Step 3: Press the reset button on the receiver.

Step 4: Follow the above 3 steps until your wireless mouse find the best-performed ID.



Features

- **Receiver stores under the mouse bottom**

Step 1: Put the mouse bottom up.

Step 2: Slide the receiver into the convex part of the mouse bottom.

Step 3: Slide the receiver tightly into the storage place in the mouse bottom.



- **Strong Power Saving**

1. Inserting receiver into the mouse bottom will turn off the power.

Push in / Power off



Push out / Power on

2. The wireless mouse has the feature of strong power saving: if you are not using the mouse, the mouse fall into „The Sleep Mode", consequently saving more power.
3. Button wake-up: Press the mouse button for re-working.

Important note

- To optimize the performance of your wireless reception, please keep your receiver at least 8 inches (20 cm) away from electronic devices, such as monitor, speakers or external storage devices.
- Please avoid using your Wireless optical mouse on a metal surface.
- Never use the wireless mouse on glass or mirrored surface.
- Use ONLY alkaline batteries. Do not mix used and new batteries in one mouse.

Copyright©2007 Mode Com Ltd. Mode Com is a registered trademark of Mode Com Ltd.

Environment protection:



This symbol on our product nameplates proves its compatibility with the EU Directive2002/96 concerning proper disposal of waste electric and electronic equipment (WEEE). By using the appropriate disposal systems you prevent the potential negative consequences of wrong product take-back that can pose risks to the environment and human health. The symbol indicates that this product must not be disposed of with your other waste. You must hand it over to a designated collection point for the recycling of electrical and electronic equipment waste. The disposal of the product should obey all the specific Community waste management legislations. Contact your local city office, your waste disposal service or the place of purchase for more information on the collection.

Weight of the device: 53g (76g including AAA batteries)

ENERGY OPTICAL MOUSE

MC-602

Wstęp

Dziękujemy za wybór wysokiej jakości myszy MC-602.

Mysz MC-602 została stworzona specjalnie z myślą o potrzebach Użytkownika, zwłaszcza takiego, który lubi pracować na notebooku. Dzięki kompaktowym wymiarom

MC-602 jest nie tylko idealna dla przenośnego komputera, ale także bardzo funkcjonalna. Bezprzewodowa technologia zapewnia wygodę użytkowania i pozwala na swobodną pracę w odległości do 2 metrów od komputera. Ponadto mysz MC-602 jest urządzeniem energooszczędnym. Charakteryzuje się wysoką rozdzielczością (800 DPI) oraz wysoką jakością wykonania. Odbiornik na USB posiada unikalne i niezwykle wygodne rozwiązanie jego przechowywania - na spodzie myszy.

Mode Com dba o jakość swoich wyrobów, by nie tylko spełniać, ale i wyprzedzać oczekiwania swoich Klientów. Produkty tworzone są w oparciu o nowoczesną myśl i technologię.

Wybierz lepszą przyszłość – wybierz Mode Com!

Zawartość opakowania

Miniaturowa bezprzewodowa mysz optyczna

Miniaturowy odbiornik USB

AAA Baterie – 2 sztuki

Instrukcja obsługi

Opis części



Podłączenie

• Wkładanie baterii

Kolejne kroki:

Krok 1: Nacisnąć przycisk.

Krok 2: Wyciągnąć osłonę baterii.

Krok 3: Włożyć dwie baterie alkaliczne AAA w miejsce przeznaczone na baterie.

Krok 4: Gdy baterie są poprawnie włożone, dioda optyczna pod myszą zaświeci się.



Ustanawianie połączenia

Mysz MC-602 jest typem myszy bezprzewodowej z funkcją „Plug & Play". Do połączenia nie trzeba ustawiać kanału. Jeżeli mysz nie działa poprawnie lub jest zakłócana przez inne urządzenie bezprzewodowe znajdujące się w pobliżu, należy wykonać następujące kroki:

Krok 1: Należy ponownie podłączyć odbiornik myszy oraz znaleźć nowy kanał komunikacyjny (ID).

Krok 2: Nacisnąć przycisk „reset” na myszy.

Krok 3: Nacisnąć przycisk „reset” na odbiorniku.

Krok 4: Postępować zgodnie z powyższymi trzema krokami aż do uzyskania najlepszego kanału komunikacyjnego (ID).



Cechy

• Odbiornik jest umieszczony pod spodem myszy

Krok 1: Ułóż mysz spodem do góry.

Krok 2: Ułóż odbiornik tak aby swoją wybrzuszoną stroną ściśle przylegał do zakończenia spodu myszy.

Krok 3: Przesuń odbiornik ku górze aby wsunąć go w miejsce do przechowywania.



• Oszczędzanie energii

1. By oszczędzać energię, należy włożyć odbiornik do myszy.

Włożony odbiornik / mysz wyłączona



Odbiornik na zewnątrz / mysz włączona

2. Bezprzewodowa mysz ma tryb oszczędzania energii: jeżeli nie używa się myszy przez 8 minut, przejdzie ona w tryb oszczędzania energii.
3. Wybudzenie: nacisnąć dowolny przycisk myszy.

Ważna informacja

- By zapewnić najlepsze działanie myszy, należy ustawić odbiornik w odległości co najmniej 20 cm od innych urządzeń elektronicznych, takich jak: monitory, głośniki i inne.
- Należy unikać pracy myszy na metalowej powierzchni.
- Nie należy używać myszy na szkle lub po powierzchni lustrzanej.
- Należy używać JEDYNIE baterii alkalicznych. Nie należy używać jednocześnie baterii starych oraz nowych.

Copyright©2007 Mode Com Ltd. Wszelkie prawa zastrzeżone. Logo Mode Com jest zastrzeżonym znakiem towarowym firmy Mode Com Ltd.

Ochrona środowiska:



Niniejsze urządzenie oznakowane jest zgodnie z dyrektywą Unii Europejskiej 2002/96/UE doty-

czącą utylizacji urządzeń elektrycznych i elektronicznych (WEEE). Zapewniając prawidłowe usuwanie tego produktu, zapobiegasz potencjalnym negatywnym konsekwencjom dla środowiska naturalnego i zdrowia ludzkiego, które mogą zostać zagrożone z powodu niewłaściwego sposobu usuwania tego produktu. Symbol umieszczony na produkcie wskazuje, że nie można traktować go na równi z innymi odpadami z gospodarstwa domowego. Należy oddać go do punktu zbiórki zajmującego się recyklingiem urządzeń elektrycznych i elektronicznych. Usuwanie urządzenia musi odbywać się zgodnie z lokalnie obowiązującymi przepisami ochrony środowiska dotyczącymi usuwania odpadów. Szczegółowe informacje dotyczące usuwania, odzysku i recyklingu niniejszego produktu można uzyskać w urzędzie miejskim, zakładzie oczyszczania lub sklepie, w którym nabyłeś niniejszy produkt.

Masa sprzętu: 53g (76g z bateriami typu AAA)

NOTES

NOTES

MODE COM®

Be satisfied... be modern...

Mode Com Ltd.
03-301 Warsaw, Poland
82 Jagiellońska St.
www.modecom.eu

MODE COM